

NOTES

1. Later models use individual red and black sockets instead of socket strips. These should be mounted at the back of the chassis with the nuts tightened firmly. Do not over-tighten. Use Reds for Aerial and 'Phone Socket connecting to battery and Black for the remaining two.
2. With the individual sockets, it may be found easier to make the "Earth" connection to chassis with a wire from Pin 9 of the coil holder to the adjacent fixing nut and bolt.