

FULLERPHONES TRENCH "S" & "W"

WIRING IS THE SAME IN BOTH EXCEPT THAT IN W THE CONNECTIONS TO 4 & 5 ARE REVERSED.

OUTGOING FULLERPHONE SIGNALS ARE HEARD IN HEAD RECVR. BUT NOT IN THE HAND TELEPHONE

OUTGOING CALLS ARE HEARD IN BOTH RECEIVERS

INCOMING FULLERPHONE SIGNALS AND CALLS ARE BOTH RECEIVED IN HEAD RECVR, THE CALLS HAVING TO GO THROUGH COILS B & A ON THE WAY. INCOMING CALLS ARE ALSO RECEIVED IN HAND TELEPHONE, IF PLUGGED IN, BUT NOT FULLERPHONE SIGNALS.

SPEAKING CAN BE RECEIVED IN THE FULLERPHONE RECVR AS WELL AS IN HAND TELEPHONE

THE BUZZER CURRENT GOES THROUGH BOTH A & B COILS, BUT THE PRIMARY CALLING CURRENT GOES THROUGH COIL B & A ONLY, THE SECONDARY CALLING CURRENT HAS TO PASS THROUGH THE BATTERY ON ITS WAY OUT TO LINE. WHILE FULLERPHONING THE HAND TELEPHONE MUST NOT BE PLUGGED OR A LOUD CONTINUOUS BUZZ IS HEARD IN BOTH RECVR'S WHILE SWITCH IS AT SEND & RECEIVE.

